

# HOW TO ADD DIRECT OUTPUT AFTER PALLETIZING CYCLE





## Log in level 16 Admin PW: pass



### Press here



### Press here



You will see your mold project files




Press + button and Expand currently loaded mold project file



## Find SecondPositionUp And OPEN it



Confirm
SecondPositionUp
is loaded




```
12 Move(pMoveTemporaryPos, vpUpCompletePos)
13 HYWaitMoveIsFinished()
14
15 IF MotionMode.i M14 > 0 THEN
   //Vertical Swivel - after traverse or in mold + trave
   CALL SwivelReturn()
18 END IF
19
20 IF bSimpleFlowChart = FALSE THEN
   // Operating Mode -> Auto
   IF (MotionMode.i M06 = 2) OR (MotionMode.i M06 = 4) T
    //Main Arm Release - Multi Point Off or Multi + Orde
    SetDO(douStackingComplete, ON)
    IF palletcount = pallet1.numberOfParts[0] * pallet
     IF (iWeightCountN1 <> 0) OR (iWeightCountN2 <> 0) Or
      PulseDO(douConveyorOff,ON, rConvOnTime, FALSE)
     ELSE
        PulseDO(douConveyorOn, ON, rConvOnTime, FALSE)
29
     END IF
30
     palletcount := 0
31
    END IF
33 ELSE
  Edit
          Selection
                      Undo
                                Remove
```

### Find and select PulseDO(douConveyorOn) line.

There is one more identical line. Make sure you select the right one.




Edit – Show Commands




### I/O Control – Pulse DO



### Modify






DO command added.

Robot will turn on DO1 for 5 seconds.

If you want to modify the command,

Selection - Modify





Kill currently opened secondpositionup



- 1) Kill currently opened master
  - 2 Open master again

#### HYROBOTICS 50% **PWR** √<sup>0</sup>) T1 20 ADMIN 16 ERR Signals palletizing Main Output Input Inter. Vacuum Y000:Vacuum OY100:Stacking Y002:Chuck Y101:InsertGripOk Y005:MainArmGrip Y102:RobotAutoRun OY104:UserOutput Y013:Rotation OY105:UserOutput2 OY014:RotReturn OY106:UserOutput3 Y015:Swivel OY107:UserOutput4 OY016:SwivelReturn OY108:UserOutput5 Y021:Vacuum2 OY109:UserOutput6 Y022:Vacuum3 OY110:UserOutput7 Y023:Vacuum4 OY111:UserOutput8 V+ OY024:SpareOutput Y203:WeightOut OY025:Ionize Y204:WeightReset Config Param Pos Proq Signals

### UserOutput1 is Y104

